



- NOTES:
1. SEE OWNER FOR SPECIFICATIONS REGARDING FURNITURE, APPLIANCES, AND CABINETY.
  2. RUN 4-OUTLET POWER STRIPS (SURGE SUPPRESSORS) ALONG BASE BOARDS FROM EXISTING POWER OUTLETS TO EACH CUBICLE. SURFACE MOUNT NEW POWER STRIPS TO CUBICLE WALLS.
  3. RUN NEW CAT-5 DATA PATCH CABLES ALONG BASE BOARDS FROM NEW DATA JACKS TO CPU LOCATIONS.